

PLEASE NOTE: THE ABOVE DIAGRAM HAS BEEN DESIGNED AS A REFERENCE ONLY. ITEMS SUCH AS THE INLET MUFFLE PIPE, FLOATING OUTAKE AND THE ADAPTER PIPE DO NOT COME STANDARD WITH THE TANK; THEY ARE ADDITIONAL EXTRAS. THIS REFERENCE WAS DESIGNED TO PORTRAY THE RECOMMENDATIONS SET OUT BY BRANZ. THIS ILLUSTRATION IS NOT ACTUAL SIZE OR DIMENSIONS.

Bowers & Sontd

Concrete Manufacturers

All dimensions are nominal & subject to manufacturing tolerances.

1852 Alexandra Street, Te Awamutu 3800 PHONE: 07 871 5209 • FAX: 07 871 5249 EMAIL: admin@bowersconcrete.co.nz